


		Номенклатура		
ПИЛА РУЧНАЯ ЭЛЕКТРИЧЕСКАЯ ЦЕПНАЯ		ПЦ-10/18В		
MANUAL ELECTRIC CHAIN SAW		GY219202		
FELISATTI		Номер на схеме	WE	
Артикул	Наименование детали		Spare part ID	
		Drawing number		
526.00010051	Дополнительная ручка	1	3121920101094001	fro
526.00020390	Ручка тормоза цепи	2	3121920201053001	fro
526.00030001	Винт	3	33SBAQA004160101	scr
526.00040022	Корпус левая часть	4	3121920101001001	lef
526.00050576	Тормозной рычаг	5	3214100301072001	bra
526.00060001	Винт	6	33SBAQA004160102	scr
526.00070395	Масляный насос в сборе	7	232219201001	Oil
	Сердечник	7-1	3194000201146001	oil
	Шестерня	7.1.2001	3290000301052001	oil
	Штифт	7.1.2002	3294000501138001	oil
	Кольцо уплотнительное	7-2	36130102	0 t
	Корпус маслососа	7-3	3114100101146001	oil
	Втулка	7-4	3290000301023001	oil
	Прокладка уплотнительная	7-5	3190000101028001	rut
	Трубка	7-6	3121920101038001	oil
	Трубка	7-7	3190000101038001	oil
526.00080001	Винт	8	33SBAQA004120101	scr
526.00090138	Кожух защитный	9	3114100301023001	Ch
526.00100402	Шина	10	3200060301007024	ba
526.00110403	Цепь	11	3200030201006002	cha
526.00120137	Упор	12	321410001155001	spi
526.00130005	Уплотнительное кольцо	13	3190000401025001	rut
526.00140087	Заклепка	14	3240100101009001	riv
526.00150228	Пластина	15	3240100401053001	reg
526.00160015	Корпус правая часть	16	3121920101002001	rig
526.00170010	Подшипник	17	33DB600002011	bea
526.00180091	Прокладка	18	329000101069001	du
526.00190032	Шестерня	19	3295000101155001	spr
526.00200091	Прокладка	20	3214100301030001	wa
526.00210011	Стопорное кольцо	21	33CC0100101	jur
526.00220391	Масляный бак в сборе	22	231219201001	oil
	Корпус маслобака	22-1	312192010147001	oil
	Насадка	22-2	3122920101148001	Oil
	Прокладка уплотнительная	22-3	3190000101148001	rut
	Уплотнительное кольцо	22-4	3190000101025001	sea
	Пружина	22-5	3290000501060001	spr
	Заглушка	22-6	3190000101081001	filt
526.00230144	Крышка	23	241229201001	oil
	Крышка	23-1	3122920201069001	oil
	Уплотнительное кольцо	23-2	3194000101028001	sea
	Щуп	23-3	3122920101161001	oil
526.00240068	Кнопка выключателя	24	3121920101157001	sw
526.00250040	Пружина	25	3221920101060001	spi
526.00260040	Пружина	26	3270000101060001	spi
526.00270209	Рычаг выключателя	27	3121920101058001	Sci


526.00280017	Выключатель	28	3422710101032001	mi
526.00290018	Контроллер	29	3421920101092001	coi
526.00300092	Ручка блокировки	30	3121920101103001	Ho
526.00310330	Скоба	31	3221920101083001	ho
526.00320493	Корпус батареи правый	32	3121920202039001	ba
526.00330019	Вилка контактная	33	3121920201049001	ins
526.00340494	Корпус батареи левый	34	3121920201039001	ba
526.00010014	Двигатель в сборе	0001 (35-61)		
526.00350046	Корпус двигателя	35	3221920101049001	Mc
526.00360037	Статор	36	3421920101005001	sta
526.00370010	Подшипник	37	33DB625002011	be
526.00380036	Ротор	38	3421920101013001	arr
526.00390001	Винт	39	33SBAQA004160101	scr
526.00400010	Подшипник	40	33DB608002011	be
526.00410002	Шайба	41	3292000101030001	wa
526.00420525	Тормозное кольцо	42	3240100101031001	br
526.00430002	Шайба	43	33WSB0080101	she
526.00440021	Гайка	44	33NAD0080101	nu
526.00450579	Тормозной ремень	45	3214100101047001	br
526.00460001	Винт	46	33SJAQA004160101	La
526.00470009	Штифт	47	3190000201156001	bal
526.00480133	Рычаг	48	3214100101050001	br
526.00490040	Пружина	49	3214100401060001	ext
526.00500259	Кронштейн	50	3122910101072001	blc
526.00510017	Выключатель	51	3422710101032001	mi
526.00520009	Штифт	52	3290000301138001	col
526.00530335	Кронштейн двигателя	53	3121920101039001	mc
526.00540010	Подшипник	54	33DB600002011	be
526.00550100	Шестерня ведомая	55	3221920201052001	big
526.00560033	Шпонка	56	3394000101077001	fla
526.00570033	Шпонка	57	3322910201077001	fla
526.00580006	Вал	58	3221920101020001	ou
526.00590021	Гайка	59	33NAD0060101	nu
526.00600002	Шайба	60	33WSB0060101	she
526.00610114	Шестерня ведущая	61	3221920101052001	sm
526.00020652	Натяжной механизм в сборе	0002 (62-71)		
526.00620001	Винт	62	33SEADA004120101	scr
526.00630405	Кольцо спиральное	63	3290000201053001	spi
526.00640011	Стопорное кольцо	64	33CC0140101	jur
526.00650144	Крышка	65	3121920101069001	cha
526.00660140	Ручка регулировки	66	3140100101058001	kn
526.00670106	Шарик стальной	67	3240100101128001	ste
526.00680040	Пружина	68	3240100101060001	spi
526.00690144	Крышка	69	3140100101053001	kn
526.00700001	Винт	70	33SBAQA004080101	scr
526.00710174	Ручка	71	3122910101058001	kn

Покупатель _____

Buyer

	Разборн:	
	ПЦ-10/18В	GY2





ный перечень деталей		1.3.2024
Spare parts list		Действителен с / Valid from
	Артикул изделия	526 .**.**.**.**
	Product ID	GY219202

LEE	Разборная схема		
Name of the spare part	Характеристика	шт.в изд	Штрих код
	Technical parameters	pcs per unit	Bar code
nt handle		1	
nt finger guard		1	
ew		14	
t housing		1	
ike block		1	
ew		2	
l pump components		1	
pump core		1	
pump humper		1	
pump pin		1	
ype ring		1	
pump housing		1	
pump sets		1	
ober gasket		1	
pipe		1	
pipe		1	
ew		2	
ain plate sheath		1	
r		1	
ain		1	
ked humper		1	
ober ring		1	
et		1	
gulating plate		1	
ht housing		1	
aring		1	
st cap		1	
ocket		1	
sher 2		1	
np ring		1	
tank components		1	
tank		1	
l can rubber nozzle		1	
ober sheath on oil tank		1	
il ring		1	
ing		1	
er screen stopper		1	
tank cap assembly		1	
tank cap		1	
il ring		1	
pot cover chain		1	
itch trigger		1	
rng		1	
rng		1	
halter den knopf		1	

croswitch		1	
ntroller		1	
ok clasp		1	
ok		1	
ltery down bracket		1	
erting seat		1	
ltery upper bracket		1	
		1	
otor - BASIS		1	
tor		1	
aring		1	
nature		1	
ew		7	
aring		1	
sher		1	
ike wheel		1	
ills pad		1	
t		1	
ike steel belt		1	
rge flat head screw		3	
kelite column		5	
ick hinge		1	
ension spring		1	
ock		1	
croswitch		1	
umns pin		2	
otor support		1	
aring		1	
g gear		1	
t key		1	
t key		1	
tput shaft		1	
t		1	
ills pad		1	
all gear		1	
		1	
ew		3	
ral plate		1	
np ring		1	
ain clamp plate		1	
ob l		1	
el ball		3	
rng		3	
ob cover		1	
ew		3	
ob		1	

Поставщик _____

Supplier

ая схема			Действителен с:
19202	526	.***.***.***	1/23/2024

